

Selectorized roller pad end cover installation procedure

Applies to

Selectorized DSL Lateral and Leg model strength equipment

Issue

Properly installing the roller pad end cap onto the plastic spacer can be a difficult process. This procedure will help you to properly install the roller pad end cap.



Example Selectorized Lat Pull Down

Tools required

• Flat head screwdriver

Procedure DSL

Review entire procedure before starting.

- 1 Place the roller pad end cover onto the plastic spacer so that at least 3 of the 5 connection points are latched behind molded disk.
- While applying pressure to the cover, carefully use a screwdriver to push the retention disk toward the cap forcing remaining connection points to snap into position. Make sure that Insure all 5 connection points are snapped into position. Cap should spin on ring if installed correctly.



Place roller pad end cover onto the spacer with at least 2 connections snapped into position.



Apply pressure on cover while using screwdriver to help snap remaining connections iinto position.

3 Verify the equipment operation and return to service